

User Manual

VP-1100-2nd-10.1

2nd LCD Monitor

CHAPTER

OVERVIEW

. INFORMATION	
2. ELECTROMAGNETIC COMPATIBILITY STATEMENT	3
3. SPECIFICATION	4
4. INSTALLATION GUIDE	5-6
4.1 Appearance	5
4.2 Install Customer Display	
5. GETTING START	7
5.1 Unpacking	7
5.2 Connection	7
6. IDENTIFY THE PROBLEM	8
6.1 Following Procedure to Troubleshoot Problems	8
6.2 Electricity Failure	
6.3 Power Failure	8
6.4 USB Failure	8
7. REPLACE FIELD REPLACEABLE UNITS (FRUS)	9-10
7.1 Safety and Precautions	9
7.2 Before You Begin	9
7.3 Replace Parts	9
7.3.1 LCD Panel	10
8 LIMITED WARRANTY POLICY	11

Overview

Thank you for purchasing the EC-TS-1100 touch screen monitor. We are committed to use up-to-date technology and provide better after-sales service continuously. Please take time to read this user manual before system installation.

Note: Information in this user manual may change without prior notice

1. Safety Information

- Make sure the power voltage is correct and the ground connection of the power outlet is working properly before plug in the electricity.
- During lightning storm, unplug the network cable, power cable and any other connections.
- Turn off power before connect any devices (except USB devices) to the terminal.
- Do not attempt to open the chassis. There is a possibility of electric shock. For service, contact the authorized service provider.
- Do not spill liquid on the monitor or place any objects into the ventilation holes. It may cause short-circuit for the internal components and cause a fire or electric shock.
- After the computer is stored below temperature of 10 degree, put the machine at room temperature (10 35 degree) in the original packing for not less than two hours to resume to room temperature before operation. This is to avoid condensation that might bring electrical damage.
- Keep the terminal clean, dry, away from dust, moisture and direct sunlight.
- Do not use harsh chemicals or strong cleaning solvents to clean the LCD or touch panel. Use a soft terry cloth with mild cleaning liquid.
- Do not share the same power outlet with high power electrical appliances, keep distance from high level magnetic interference.
- Do not use sharp pointed objects to operate, it will cause damage to the screen.

When the following occurs:

- Water go in the LCD monitor;
- Physical damage accidentally;
- Burning smell from the monitor;
 - disconnect the power supply immediately, unplug the power cord and contact a qualified service technician.

2. Electromagnetic Compatibility Statement

FCC NOTICE

This device complies with Part 15 of FCC Rules. Operations are subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

EUROPEAN COMMINITY (CE) MARK FOR CONFORMITY

This product is in conformity with the protection requirements of EU Council Directive 2014/30/EU on the approximation of the laws of the Member States relating to electromagnetic compatibility. Logic Controls cannot accept responsibility for any failure to satisfy the protection requirement resulting from non-recommended modification of the product. This product has been tested and found to comply with the limits for Class A Information Technology Equipment according to CISPR 22/European Standard EN 55022. The limits for Class A equipment were derived for commercials and industrial environments to provide reasonable protection against interference with licensed communication equipment.

3. Specification

VP-1100-2 nd -10.1 2nd Monitor		
DISPLAY	Display Size	10.1 Inch
	Resolution	1280 × 800
	Brightness/Backlight Type	400cd m2 (LED)
	Contrast Ratio	600 : 1
	Response Time	25 ms
	Viewing Angle (Up/ Down/ Left/ Right)	80° /80° /80° /80°
	I/O Connection	1 X VGA
		1 X 12V DC Input
PHYSICAL	Housing Material	Plastic
	Tilt Angle	0 - 270°
	VESA Mounting	75mm × 75mm
	Dimensions (W x D x H)	263 (W) x 22 (D) x 178 (H) mm
	Packing Dimension	320 (W) x 65 (D) x 222 (H) mm
	Net Weight	N.W. 0.82 Kg
	Gross weight	G.W. 1.00 Kg
ENVIRONMENTAL	Consumption	25 MAX
	Operating Temperature	-10°C ~ 50°C (14°F ~ 122°F)
	Storage Temperature	-20°C - 60°C
	Humidity	10% - 85%
	Shock / Drop	Prohibited
POWER	Power Input	12V - 2A

4. Installation Guide

4.1 Appearance

4.1.1 Font View




4.1.2 Rear View



VP-1100-2nd-10.1 User Manual

4.2 Install LCD Display

- Disassemble the LCD Display
 Protective Cover
- 2. Connect the Monitor's LCD Display USB I/O Port to PC's USB Ports



5 Getting Start:

This chapter describes preparation before use the VP-1100-2nd-10.1 LCD Monitor. The following topics are described.

5.1 Unpacking

Below are the items should include in the carton box:

- EC-VP-1100-2nd-10.1 X 1
- Screw X 2

If any of the above item is missing, please contact you dealer.

5.2 Connection

After unpacking the carton, connect the USB I/O cable properly to the rear top of VP-1100 / VP-3100

6 Identify the Problem

6.1 Follow the procedure below to troubleshoot the problems:

- Identify all the symptoms in detail
- Verity symptoms by re-create them
- Follow corrective procedures in order
- If you replace an FRU and the symptom still exists, install the original part and do another test to identify the problem

6.2 Electricity Failure

Power failure can be caused by loose connection of the power cable, or undetermined problems

6.3 Power Failure

Power shut down unexpectedly cannot turn on the monitor

- Check the power cable
- Check the alignment of the power button cable

6.4 USB Failure

- Check the ports which detected in Windows Device Manager
- Reset the USB device
- Reinstall the USB device driver
- Replace the USB device

7 Replace Field Replaceable Units (FRUs)

7.1 Safety and Precautions

Monitor components and electronic circuit boards can be damaged by discharges of static electricity, continuously working on those monitor that are still connected to a power supply can be extremely dangerous. Follow these guidelines to avoid damage to the computer or injury to yourself.

- Always disconnect the unit from the power outlet
- Leave all components inside the static-proof packing that they ship with until they are ready for installation
- After replacing optional devices, make sure all screws, springs, or other small parts are placed tightly, no left over inside the case. Metal parts or flakes can cause electrical shorts

Caution

- Only qualified personnel should perform repairs on the monitor. Damage due to unauthorized servicing is not covered by the warranty
- If the LCD breaks, pay attention for the fluid spill to the skin or eyes. Immediately wash with water and seek medicals attention
- Under no circumstances to touch the inverter card while power is connected to the monitor.
 Unplug the power cord before attempting to replace any FRU
- To prevent static damage to components, wear a grounded wrist strap. Alternatively, discharge
 any static electricity by touching the bare metal chassis of the unit case, or the bare metal body
 of any other grounded appliance
- Hold electronic circuit boards by the edges only. Do not touch the components on the board unless
 it is necessary to do so.

7.2 Before You Begin

Make sure you have a stable and clean working environment. Dust and dirt can get in to Mercury components damaging the internal components.

Most of the electrical and mechanical connections can be disconnected by using your fingers. It is recommended that you do not use needle-nosed pliers to disconnect as these can damage the soft metal or plastic parts of the connectors.

- To prevent scratching the case, make sure the table top surface is clean and flat
- If you need to put the display face down, be sure to use a foam mat underneath for protection purpose


7.3 Replace Parts

Take note of the following when replacing parts:

- If you replace an FRU and the symptom still exists, install the original part and do another test to identify the problem
- When replacing a falling part, other parts that have to be removed before the falling part are listed at the top of the page
- To replace a part, reverse the removal procedure

7.3.1 The LCD panel

- 1. Tear up the black lid
- 2. Disconnect the cables
- 3. Remove 4 screws, then take out the LCD panel



VP-1100-2nd-10.1 User Manual - 10 -

8 Limited Warranty Policy

The EC-TS-1100 Touch Screen Monitor features a one-year-limited warranty from the date of purchase. If product is determined to be defective, we will repair or replace the product with refurbished or remanufactured parts or components during the warranty period.

This warranty is valid only for the first consumer purchaser.

This warranty does not cover cosmetic damage or damage due to acts of god, accident, misuse, abuse, negligence, commercial use or modifications of, or to any part of the product.

This warranty does not cover damage due to improper operation or maintenance, connection of improper voltage supply, or attempted repair by anyone other than a facility authorized by us to service the product.

This warranty does not cover irregular pixel performance on the screen, and damages result due to delivery or improper shipping. This warranty does not cover product sold AS IS or WITH ALL FAULTS, and failure to follow instructions supplied with the product.

This warranty is invalid if the factory-applied serial number has been altered or removed for the product and broken security seal.

The customer must have model number, serial number, and original proof of purchase in the form of a bill of sales or receipt invoice, which is evidence that the unit is within the warranty period, must be presented to obtain warranty service. Our helpful technical support and customer service staff will attempt to correct any minor issues that might be causing the product failure. If the technical service or customer representative is unable to fix the issue by phone, a return material authorization (RMA) number will be issued. Along with the proof of purchase and the RMA number, the customer can ship the defective unit back to us. Once the defective unit is received and tested, we will ship a replacement unit back to customer. It is the responsibility of the customer to properly package the terminal with plugs, power supply, etc.

We shall not be liable for the loss of the use of the product, inconvenience, loss or any other damages, direct or consequential, arising out of the use of, inability to use, or any claim against the customer by any other party. Some regions do not allow exclusion of incidental or consequential damages, so the above limitations and exclusions may not apply to you.

VP-1100-2nd-10.1 User Manual - 11 -

Manufacturer: EC LINE

Thank you very much for using EC Line product

For service, please contact service@ecline.com.hk

www.eclinepos.com



VP-1100-2nd-10.1 User Manual - 12 -