![EC Line logo - True value in POS]

EC-i6200S Quick Start Guide

Important notice on lithium ion battery

1) Charge the battery only with original EC Line power adaptor supplied in the box
2) Do not store the device with battery installed for long period of time
3) If long period storage is required, remove battery from device
4) During long storage period, maintenance work is required at every 3 months period. During maintenance, discharge the battery completely, and then charge to 60% - 70% (or 3.8V - 3.9V)
5) Store battery in dry, cool environment. Temperature should be -20 to 40 degree Celsius and relative humidity should be 45% to 85%
6) Charge battery at 5 to 45 degree Celsius
7) Do not operate the device outside the recommended temperature, which is from -20 to 60
8) Do not install a third party battery into EC Line device

Safety Precaution

1) Do not transport the battery at temperature higher than 65 degree Celsius
2) Do not expose battery to fire or heat source
3) Do not forcefully install the battery in opposite direction into the device
4) Avoid impact and high vibration force on the battery
5) Keep battery dry at all time
6) Do not use battery that is damaged or appear to have been modified
7) Do not use unauthorized power adaptor to charge the battery
8) Do not discharge the battery beyond the specification of the battery
9) Do not place battery into microwave oven or pressured container
10) Do not damage battery with sharp objects
11) Do not operate in environment with extreme electrostatic fields or magnetic fields
12) If leakage found in battery, avoid contact with body parts Should leakage be in contact with body parts, flush with water and immediately seek medical attention
13) If battery exhibits unusual behavior like color change, temperature became hot, shape is swollen, remove battery from device and stop using that battery
14) If the contact point on the battery is dirty, clean with a dry cloth
15) Dispose the battery according local regulation. Recycle if possible
16) Improper usage or storage may cause battery performance to drop, leak, damage, or even escalate to personal safety issue

Appearance and Buttons

Front View

LED indicator

Touch screen

Main key pad

To turn on: Hold power button until device switches on
To turn off: Hold power button until the device screen shows the power off menu
Select shutdown on the menu
Sleep: Under operation mode, press the power button once
Wake up: Press power button once

Side View

POGO pin connector for cradle charging

Scan engine window

Power button
Scan button
Volume control
Reset button

Audio jack
USB connector
Scan button
User define button

Rear View

PSAM Slot
Micro SD card slot
SIM Slot
Speaker
Camera and LED flash

Contactless reader
Battery lock

Battery Installation

Insert the battery into the battery compartment as shown in the picture
Battery should sit tightly in the compartment when correctly installed
Do not apply excessive force when inserting the battery

Charging Using Cradle

C Indication light
P Indication light

Battery Slot
Device Slot

Power Adaptor

Connect the power cable into the cradle
P: LED indicates the cradle is operational
Slot the device into the cradle and take note of the LED change on the device which indicate the charging process
Slot the battery into the cradle as shown in the picture
C: LED should lit up to indicate charging

Battery Operation

The device battery is polymer type battery, which should only be charged by using original EC Line power supply
Metal contact is unavailable or artificial short circuit electrode
Do not store battery in hot, humid, or corrosive environment
Do no break or crack battery
Do not store battery when it is fully charged completely drained
If device is not used for long period of time, remove the battery from the device

If the battery is misshapen or is found leaking, replace the battery immediately
Note: The battery should be charged for at least 8 hours before the first use

Installing SIM/ TF Card

1. Swing open the main battery cover clip by 90 degrees, you can then remove the battery cover
2. Insert the SIM card or Micro SD/TF card into their corresponding slots in the battery compartment
Note: You should gently push the SIM/TF card to the correct position without using excessive force

Connecting to PC

After you install the Android driver or an Android smart phone assistant, you can connect the devices to your PC with USB cable provided
You can download the software mentioned above from http://www.eclinepos.com
After device connected to your PC, the screen would display like this:

After the device connected to your PC, you could drag the top part of the screen down to show the USB options

Select this option to enable / disable device as USB storage to the PC

Select this option to enable / disable USB debugging

Check this to enable USB debugging

Check this to enable device as USB storage to PC

Note: When you enable device as USB Storage to PC, the flash memory of the device are map as a PC drive

At this point of time, you cannot install APK to the device

To install APK to the device, it should not be in USB Storage mode